

as 4/26/12

## Assembly Instruction For 20097

Step 1. Insert the shorter pole into the base, fixed with screw.

Step 2. Insert the longer pole into the short pole, fixed with clip button.

Step 3. Put the cotter pin through the bottom hole on the pole, slide one bearing, one basket down the pole. Then repeat the step for other 3 baskets using different holes upwards.

Step 4. Insert the sign holder into the top pole.

