

4/2012

Assembly Instruction For 3213

Step 1. Insert the longer pole into the base, fixed with screw.

Step 2. Insert the shorter pole into the longer pole, fixed with clip button.

Step 3. Put the cotter pin through the lowest hole on the pole, slide one bearing, one bushing, one round washer down the pole in turn, then repeat another 2 sets in the same way.

Step 4. Hang the pocket panels onto the washers.

Step 5. Insert the Sign holder into the pole.

