

# #4998 Bulb Installation



1. Unplug unit and let bulbs cool down for 5 minutes.



2. Pinch prongs together and gradually pull down locking ring. Locking ring will come off.




3. Push bulb into the unit and gently twist until the bulb comes down.



**4. Gently hold and pull bulb down from socket**



**5. Align bulb prongs into socket and push new bulb into socket.**



**6. Push bulb into unit and twist. The bulb will remain in place if done correctly.**



**7. Insert locking ring, the ring will click in place when inserted correctly.**

