

6029

Instruction Manual

(DEP-TN508A)

1. Opening the Safe Using the Opening Index

1) If the safe comes with a factory-set combination on 50-50-50, turn the dial to the LEFT and pass the number 50 three times and then stop exactly with 50 lined-up on the OPENING index the fourth time. Turn RIGHT until the dial stops, and the safe is opened.

2) To open a safe with a previously-set combination, for example, 10-20-30

a. Using the Opening Index, turn the dial anticlockwise and pass the first number of the combination (10) three times and stop exactly on 10 on the fourth time.

b. Turn the dial clockwise and pass the second number of the combination (20) two times and stop exactly on 20 on third time.

c. Turn the dial anticlockwise and pass the third number of the combination (30) once and stop exactly on 30 the second time.

d. Turn the dial clockwise. When the lock is open, the dial will not turn to the right any more.

To lock the combination lock, turn the dial four complete turns anticlockwise.

2. Changing the Combination on the Changing Index

Note: To change the combination, you will need access to the existing combination and a La Gard Group 2 change key.

1) **To change the factory-set combination 50-50-50 into a new code, for example, 40-50-60**

a. Turn the dial anticlockwise and pass the number 50 three times and stop exactly with 50 lined-up on the OPENING index the fourth time. Turn the dial clockwise until the dial stops. The safe is opened.

b. **Turn the handle and make sure the bolts are not retracted**, turn the dial anticlockwise and pass the number 50 three times and stop with 50 lined-up on the CHANGING index the fourth time. Fully insert the La Gard Group 2 change key (the hole is on the back of the door). Turn the change key clockwise until it stops.

c. turn the dial anticlockwise and pass the first number of the combination (40) three times and stop exactly with 40 lined-up on the CHANGING index the fourth time.

d. Turn the dial clockwise and pass the second number of the combination (50) two times and stop exactly with 50 lined-up on the CHANGING index the third time.

- e. Turn the dial anticlockwise and pass the third number of the combination (60) once and stop exactly with 60 lined-up on the CHANGING index the second time.
- f. Turn the change key anticlockwise and pull out the key.

2) If the factory-set code 50-50-50 is changed into 40-50-60, how to change 40-50-60 into another new code, for example, 60-50-40

Note: Make sure the door is opened, while the bolts are not retracted.

- a. Turn the dial anticlockwise and pass the number 40 three times and stop exactly the fourth time with 40 lined-up on the CHANGING index.
- b. Turn the dial clockwise and pass the second number of the combination (50) two times and stop exactly the third time with 50 lined-up on the CHANGING index.
- c. Turn the dial anticlockwise and pass the third number of the combination (60) once and stop exactly the second time with 60 lined-up on the CHANGING index.
- d. Fully insert the La Gard Group 2 change key (the hole is on the back of the door). Turn the change key clockwise until it stops.
- e. Turn the dial anticlockwise and pass the first number of the combination (60) three times and stop exactly with 60 lined-up on the CHANGING index the fourth time.
- f. Turn the dial clockwise and pass the second number of the combination (50) two times and stop exactly with 50 lined-up on the CHANGING index the third time.
- g. Turn the dial anticlockwise and pass the third number of the combination (40) once and stop exactly with 40 lined-up on the CHANGING index the second time.
- h. Turn the change key anticlockwise and pull out the key.

Note: All the changing code process needs to be done when the safe is opened, and the bolts are not retracted (when the door is opened, turn the handle to turn the bolts out and make sure they are not retracted)

